# Operating and Maintenance Instructions HAKU Pipe Saddle With ZAK® Outlet and Auxiliary Shut-off Facility Ord.No. 522-00



# 1. Intended use / product description



**Medium:** Potable water

Max. operating temperature: 0° to 40°

Max. operating pressure: 16 bar

Material: Body: GJS-400, Hawle epoxy powder coating

Gaskets: water: EPDM acc. to UBA-KTW-BWGL

Screws, washers: stainless steel

Auxiliary shut-off facility: glass fibre reinforced POM

HAKU pipe saddles with ZAK® socket outlet and auxiliary shut-off facility are to be used for installation on PE pipes PE80/100 acc. to DIN 8074/DIN EN 12201 and PVC pipes acc. to DIN 8062/DIN EN ISO 1452-2. The two saddle halves are exactly calibrated to the respective outside diameter. When connecting the saddle halves, an inadmissible deformation of the pipe is prevented by metal stops.


In combination with a pipe drilling device (e.g. Hawle drilling device HAWLOMAT, Order No. 830-00) the shut-off system with integrated auxiliary shut-off facility permits an easy and trouble-free drilling of the main line, even with the line in service.

On drilling, the outlet area is temporarily shut off via a shut-off blade (model no. 840-00) after pulling out the drilling spindle. The shut-off blade is available as accessory.

After drilling, valves and fittings with ZAK® spigot end can be integrated via form-fit connection.

During installation and maintenance operations, the applicable standards and guidelines, accident prevention regulations and the regulations of professional associations are to be observed and complied with. Installation and maintenance operations may be performed by qualified personnel only.

## **Accesoires:**



#### 2. Assembly



Open-ended wrench, torque wrench

- 1. The surface of the pipe must be free from dirt, soil, or grease, and the pipe has to be cleaned accordingly.
- 2. Place the HAKU shut-off saddle at the desired position.
- 3. Fix the HAKU top and bottom halves by means of the four screws included in the scope of supply, observing following torques:

M10: max. torque 50 Nm M12: max. torque 70 Nm M14: max. torque 80 Nm M16: max. torque 90 Nm

#### Standard installation:

Tighten the hexagon head screws evenly and crosswise until the two parts get in contact and the maximum torque is reached.

Important: Do not use any extensions!

## Installation on old pipes:

When the pipe saddle is to be installed on existing PE lines (old pipes), the outside diameter may be beyond the standard tolerance. Pretighten the HAKU with two longer screws, if necessary.

After final assembly of the saddle, check the maximum torque twice after 15 minutes, each!

4. Drill the pipe using the HAWLE drilling device. Observe the relevant operating instructions.

On drilling, the bore is temporarily shut off by means of a suitable shut-off blade/saddle blade Ord. No. 840-00 (see accessories) after pulling out the drilling spindle. The saddle blade is available as accessory.

## 3. Commissioning and pressure-testing

After the successful installation, the device has to be subjected to pressure testing in the open trench considering the maximum operating pressures as specified in the DVGW regulations.

# 4. Servicing and maintenance

Hawle HAKU pipe saddles do not require any maintenance.

# If you have any other questions or if you need more information, please contact:

Hawle Armaturen GmbH
- Application Engineering Liegnitzer Str. 6
83395 Freilassing

Telephone: +49 (0)8654 6303-0 Telefax: +49 (0)8654 6303-222 E-Mail: info@hawle.de Internet: www.hawle.de